

Recommended Overlaminates for Australian One Way Vision Films

As at 21 March 2019

Please refer to the Laminating Fact Sheet for further information.

IMPORTANT: Performing a test prior to actual production can minimise costly errors and help to ensure the success of your project.

Window Film	Recommended Overlamine
AutoVue	CurvaLam
BannerVue	Not applicable
ClassicVue	CurvaLam
ClearVue Interior	Not Applicable
EconoVue	Do not overlamine
ExitVue	CurvaLam (Do not laminate if applied to emergency exit windows)
Fast One Way	Do not overlamine
JetVue	CurvaLam
PosterVue	Do not overlamine
PromoVue	CurvaLam
RetailVue	Not applicable
SuperVue	CurvaLam
SunSecure	CurvaLam